

# Maximizing Performance of Electronic Initiation with Signature Hole Analysis Techniques

Stuart Brashear



QUARRY  
ACADEMY

Improving Processes. Instilling Expertise.

**DYNO**  
Dyno Nobel

**SANDVIK**

# Agenda

- **What is Signature Hole Analysis (SHA)?**
- **How it works**
- **What it can do**
- **What it can't do**
- **How to collect data**
- **How to analyze data**
- **Troubleshooting**


# What Is SHA

- **Allows for modeling seismic effects of any blast design**
  - ✓ **Site specific**
  - ✓ **Sensitive to changes in shot designs**
- **Can determine optimum firing sequences for minimizing off site impact**
  - ✓ **Reduced low frequency amplitude**
  - ✓ **Reinforce high frequency spectra**
- **Can determine optimum shot geometry**
  - ✓ **Number of holes/row**
  - ✓ **Number of rows**


# How SHA Works

- **Uses superpositioning of waves**
  - ✓ **Waves can be added together**
  - ✓ **Relative position to each dictates the resulting, complex waves**
- **Done by digitizing seismic data**
- **Digitized wave data is summed to represent multiple hole detonations**
- **Critical for use with electronic detonators**

# Linear Superpositioning




# Linear Superposition




No delay

# Linear Superposition



8 ms delay


# Linear Superposition



67 ms delay




# Linear Superposition




42 ms delay

# Linear Superposition



92 ms delay

# Linear Superposition




115 ms delay

# Linear Superposition




## Selected Signature Waveforms

sm141520030817081.dtb




Single hole – 0.175ips

# Linear Superposition




5 holes – 0 delay  
0.878 ips

# Linear Superposition




5 holes – 9ms delay  
0.597 ips

# Linear Superposition



5 holes – 17ms delay  
0.430 ips


# Linear Superpositioning



5 holes – 25ms delay  
0.246 ips




# Linear Superpositioning



# Linear Superpositioning

Hole	R	V	T	RHz	VHz	THz
37	0.179	0.134	0.087	3.75	8	4
38	0.181	0.143	0.089	3.75	7.75	3.75
39	0.202	0.158	0.098	22.75	7.75	3.75
36	0.207	0.143	0.087	3.75	8	4
29	0.225	0.175	0.096	4	5.25	4
28	0.227	0.172	0.101	4	5.25	4
27	0.228	0.167	0.107	4	5.25	4
35	0.229	0.155	0.083	3.75	9.25	4
40	0.23	0.176	0.105	22.75	24	3.75
26	0.231	0.19	0.11	4	5.25	4
32	0.238	0.174	0.081	4	5	4
30	0.242	0.176	0.091	4	5.25	4
31	0.245	0.177	0.085	4	5	4
25	0.246	0.219	0.111	4	5.25	4
33	0.25	0.168	0.081	3.75	5	4
34	0.251	0.16	0.078	3.75	3.75	4
41	0.261	0.194	0.111	22.5	24	7
24	0.263	0.245	0.127	4	5.25	4
23	0.275	0.269	0.14	4	5.25	4
22	0.28	0.29	0.151	4	5.5	4
42	0.299	0.207	0.114	22.5	21.75	7
21	0.281	0.305	0.159	4	5.5	4

# Linear Superpositioning



5 holes – 37ms delay  
0.179ips

# What SHA Can Do

- **Eliminate “train wreck” delay choices**
- **Assist in meeting regulatory limits**
- **Reduce structure response in neighboring structures**
  - ✓ Reduce human perception of event
  - ✓ Reduce complaints
  - ✓ Minimize risk of litigation
- **Assist in blast program development**
  - ✓ Project effects for different shot sizes

# WHAT SHA Cannot Do

- **Predict actual ppv values**
- **“Shift” energy to higher frequencies**
- **Take into account confinement or other blast variables**

# Other Effects of SHA

- **By optimizing for use of electronic detonators...**
  - ✓ Reduce oversize (axial priming)
  - ✓ Improve overall fragmentation
  - ✓ Customize muckpile profile
  - ✓ Enhance crusher throughput
  - ✓ Improve cycle times
- **Allows you to use your loading equipment for alternative chores...**



# The SHA Process

- **Determine current and future mining areas of concern**
- **Identify critical and/or regulatory structures of interest**
- **Develop test hole program**
- **Determine seismic arrays**
- **Document locations**
  - ✓ **Test holes**
  - ✓ **Seismographs**
- **Load and shoot test holes**
- **Process raw seismic data**
- **Analyze shot designs**



# Determine Hole Locations

- **Orientation of benches**
- **Changes in rock characterization**
- **Prominent localized geologic conditions**
- **Significant changes in elevation**










# Determine Seismograph Locations

- **Criterion**

- ✓ **Regulatory interest**
- ✓ **Complaint interest**
- ✓ **Distance from test holes**
- ✓ **Orientation relative to test holes**

- **Create array if needed**

- ✓ **Near field – guaranteed data**
- ✓ **Mid field – probably “good” data**
- ✓ **Far Field – closest to structure that will trigger unit**




# Document Locations

- **Use GPS to record test hole locations**
- **Use GPS to record seismograph locations**
- **Critical to keep data straight**



Waypoints			
Label	Type	Description	Distance to Active Po
TH-6	Hole	Top Bench - west	231.95 ft
TH-5	Hole	Level 1 - west	120.75 ft
TH-4	Hole	Level 2 - south	448.11 ft
TH-3	Hole	Level 2 - west	251.70 ft
TH-2	Hole	Level 5 - west	0 ft
SL - 9	Seismogram	55 Vintage Rd	2849.43 ft
SL - 8	Seismograph	76 Vintage Rd	3559.73 ft
SL - 7	Seismograph	78 Vintage Rd	3681.10 ft
SL - 6	Seismograph	Farm @ 102 Vintage Rd	4443.27 ft
SL - 5	Seismograph	Wils Residence, Vintage Rd	5475.36 ft
SL - 4	Seismograph	788 Strasburg Rd - farm drive	4615.93 ft
SL - 3	Seismograph	92-96 McIlvane Rd driveway	1918.05 ft
SL - 2	Seismograph	34 McIlvane Rd	1324.02 ft
SI - 13	Seismograph	829 Strasburg Rd	5481.66 ft
SL - 12	Seismograph	54 Vintage Rd	1758.91 ft
SL - 11	Seismograph	Hess Mills Parking lot	1977.79 ft
SL - 10	Seismograph	27 Vintage Rd	2358.69 ft
SL - 1	Seismograph	Smith Residence Mcilvane Rd	1438.98 ft



# Load test holes

- **Nominal burden**
- **Nominal depth**
- **Nominal hole diameter**
- **Nominal subdrill**
- **Nominal explosive loading**
- **Single initiation source**

# Deploy Seismographs

- **Insure good coupling of geophones**
  - ✓ **Buried**
  - ✓ **Spiked and sandbagged**
  - ✓ **Never use spikes only!!!!**
- **Synchronize internal clocks**
  - ✓ **Aids in assigning event data to specific shots**
  - ✓ **All shots might not trigger all seismographs**
- **Set trigger levels to 0.05 ips**

# Fire Signature Holes

- Determine order of firing
- Shoot from bottom of pit to top
- If possible, separate detonations by several minutes
- Record shot times




# Process data for analysis

- **Download data asap**
- **Check waveforms for conformity**
- **Place all needed data in headings and save with event**
  - ✓ **Test hole number or location**
  - ✓ **Seismograph location**


# Analyze for shot

- **Limitations of software**
  - ✓ **Single inter hole delay**
  - ✓ **Single inter row delay**
  - ✓ **Variable holes per row**
- **Must determine order of initiation to define holes and rows**
- **V-cut shots are problematic**
  - ✓ **Must maintain inter hole timing**
  - ✓ **Results in doubled actual delay between holes on each side of shot**

# Defining Rows



# Defining Rows




Row 1 – 7 holes  
Row 2 – 7 holes  
Row 3 – 4 holes



# Defining Rows




# Defining Rows



# Run analysis

- **With electronic detonators, optimum sequences can change shot by shot**
- **With properly set up data, analysis for each shot is possible**
- **Removes need to maintain exact shot pattern to be effective**
- **Using correct data file, run analysis for shot specific design**



# Troubleshooting

- **Are you using the correct signature waveform ?**
- **Do you have the right design ?**
  - ✓ Holes per row
  - ✓ Rows
- **Has something changed at the quarry ?**
  - ✓ Distance to seismograph
  - ✓ Geology between shots and seismograph
- **Are sound blasting practices still being employed ??**

[www.quarryacademy.com](http://www.quarryacademy.com)



Improving Processes. Instilling Expertise.

**DYNO**  
Dyno Nobel

**SANDVIK**